

## Modem script for MAC OS X

Date: 02 - 2006

Document No.: 95-123060

### How to install the modem script:

- Copy "Thrane & Thrane EXPLORER 500" into "/Library/Modem Scripts".
- When an EXPLORER 500 is connected it will be listed in the Network pane in System Preferences.
- Go to the Network pane and select the EXPLORER 500.
- On the modem tab select the "Thrane & Thrane EXPLORER 500".